

# Fitting Instructions #ALOY0004IS

## Subaru Impreza WRX

### Front Lower Control Arm Inner Rear Bushing (Aftermarket Arm)



**Note:** Alloy Arm must be fitted to both sides of the vehicle.

- Wheel-align the vehicle before the job is started and note settings;
- Jack the vehicle up and support on jack stands;
- Remove the factory front lower control arms;
- With the new ALOY kit purchased, you will need to install the rear bush.
- Slide the bigger diameter washer until it comes up against the shoulder. Ensure the inner race section of the washer faces the bush.



- Slide the bush towards the washer. **Note:** the bigger diameter of the rear bush goes in first (see picture below).



- Insert the smaller diameter washer ensuring that the inner race section of the washer faces the bush.



- Screw the nut and tighten to 190N-m with a torque wrench.



- Fit the new ALOY control arm to the vehicle. Tighten all bolts to manufactures torque settings.
- Carry out wheel alignment.